



X-ray module

MesoFocus 450



High power and system availability

Combining the module's excellent performance and high throughput makes the MesoFocus module ideal for inline inspection and 24/7 operation. The MesoFocus module reduces inspection times up to 60%, compared to standard open-microfocus modules, because of the higher penetration power and highest system availability for the 25 – 500 micrometers inspection application range.

Stability, repeatability, and accuracy

The MesoFocus technology enables a stable dose rate without the need for recalibration during the scan. The results are consistent image quality and reproducibility, which is vital for long-term CT scans where stability is crucial. The MesoFocus module ensures repeatable and accurate inspection results and measurements vital in mass production inspection.

Low maintenance, high uptime

The robust and sealed design of the MesoFocus tube allows for 24/7 operation in harsh environments. The sealed tube design does not need frequent maintenance, and it is not sensitive to dust, oily environments, humidity. The modules' predictive maintenance capabilities enable scheduled maintenance - making production planning easy and ensuring maximum uptime.

Product Specifications

MesoFocus 450		450/1.0
Nominal voltage		450kV
Voltage range		100 - 450kV
Focal spot Ø **	63µm FS18	50W
	100µm FS16	100W
	250µm FS13	250W
	350µm FS11	350W
	450µm FS10	450W
Inherent filtration		5 mm Be
Target material		W
Target angle		20°
Radiation coverage		40° x 40°
Minimal focal spot to object distance FOD		60mm
Working point change		< 6s
Absolute voltage accuracy		± 1 % of max kV
Long term voltage stability*		± 0.1 % of max kV
Temperature-induced drift on kV		± 40 ppm/°C
Emission current range		0 - 2 mA
Absolute current accuracy		± 0.01mA
Current reproducibility		± 0.002 mA
Long-term current stability*		± 0.1 % of set mA
Temperature-induced drift on mA		± 50 ppm/°C
Communication interface		Ethernet
Expected tube lifetime	63µm / 50W:	>25'000h
	100µm / 100W:	>15'000h
	250µm / 250W:	>10'000h
	350µm / 350W:	> 8'000h
	450µm / 450W:	> 5'000h
Typical dose rate decrease per 1000 cycles		<0.1%
Typical dose rate decrease per 1000 hours		<0.2%
High-voltage connector type on tube side		R28
High-voltage connector type on generator side		R28
Tube weight		47.6 kg
Tube dimensions D x L		170 x 555.5 mm
Generator weight		292 kg
Generator dimensions W x H x L		578 x 1021 x 709 mm
Gapping spring-loaded terminal		2 rings visible, -7mm
Gapping non spring-loaded terminal		5.5 - 6 mm
Grease quantity for high voltage cable	1.4 ml (tube side)	
	1.4ml (generator side)	
Approvals	PTB, M+C7:C31ET-NRTL, NFC 74-100	
Leakage radiation in 1 m distance		10 mSv/h

* Over 8 h max. kV / power after 1 h warm-up

** according ASTM E1165-20

Comet AG

3175 Flamatt
Switzerland
xray.comet.tech



General Information

For more information and instructions regarding operation and installation of iXRS X-ray modules, cooling, connection of the X-ray tube and radiation protection, please consult the iXRS operator manual.

iXRS Configuration

For your individual iXRS configuration, please consult our website.

Power Rating Diagrams

